

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

BRONICA											
---------	--	--	--	--	--	--	--	--	--	--	--

ETRSi/SQ-Ai	SCA 386 ²⁾ + SCA 300E	SCA 386 ²⁾	SCA 386 ²⁾	SCA 386 ²⁾ + SCA 300E	SCA 386 ²⁾	SCA 386 ²⁾ + SCA 300E	SCA 386 ²⁾ + SCA 300E	11)	SCA 386 ²⁾ + SCA 300E	SCA 386 ²⁾	SCA 386 ²⁾ + SCA 300E
-------------	--	-----------------------	-----------------------	--	-----------------------	--	--	-----	--	-----------------------	--

CANON											
-------	--	--	--	--	--	--	--	--	--	--	--

A-1/AE-1/F-1 New/AV-1/AL-1/EF-M/ AT-1/AE-1 Program/ T50/T70/T80/T90	SCA 311 ⁸⁾	SCA 311 ⁸⁾ + cable SCA 300 A	SCA 311 ⁸⁾ + cable SCA 300 A	SCA 311 ⁸⁾	SCA 311 ⁸⁾ + cable SCA 300 A	SCA 311 ⁸⁾	SCA 311 ⁸⁾	11)	SCA 311 ⁸⁾	SCA 311 ⁸⁾ + cable SCA 300 A	SCA 311 ⁸⁾
EOS 700/750/850/RT/600/620/630/650/ 1000/1000N/1000F/1000FN/REBEL/ REBEL S/1/1V/100/ELAN/50/50E/ 55/500/500N/IX/IX7/3/30/ 33/300/300N/ELAN 2/ELAN 2E/5/ 10/10s/3000/3000N/5000/A2/A2E	SCA 311 ⁸⁾	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 3102 onwards M	11)	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M
EOS 30V/33V/300V/3000V	SCA 311 ⁸⁾	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 311 ⁸⁾	11)	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M
EOS 1N	standard foot 301 ⁷⁾	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M	SCA 3102 onwards M	11)	SCA 3102 onwards M	SCA 3102 onwards M + cable SCA 3000 C	SCA 3102 onwards M
EOS 300X	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾	SCA 3102 onwards M2 ⁷⁾	11)	SCA 3102 onwards M2	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾



Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

Power Shot Pro70	standard foot 301 ⁷⁾	SCA 3102 onwards M2 + cable SCA 3000 C	SCA 3102 onwards M2 + cable SCA 3000 C	SCA 3102 onwards M2	SCA 3102 onwards M2 + cable SCA 3000 C	SCA 3102 onwards M2	SCA 3102 onwards M2	11)	SCA 3102 onwards M2	SCA 3102 onwards M2 + cable SCA 3000 C	SCA 3102 onwards M2
EOS D30/D60/1D/1DS/10D/300D/ Power Shot G1/G2/G3/G5/Pro 90IS/Pro1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾	SCA 3102 onwards M2 ⁷⁾	11)	SCA 3102 onwards M2	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M2 ⁷⁾
EOS 350D/400D/20D/30D/5D/1D Mark II/ 1D Mark II N/1DS Mark II/ Power Shot G6/G7	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M3 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M3 ⁷⁾	SCA 3102 onwards M3 ⁷⁾	11)	SCA 3102 onwards M3	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M3 ⁷⁾
EOS 450D/40D/50D/500D/1000D/ 5D Mark II/1D Mark III/1Ds Mark III Power Shot G9/G10/G11/S5 IS/SX1 IS/SX10 IS/SX20 IS	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M4 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M4 ⁷⁾	SCA 3102 onwards M4 ⁷⁾	11)	SCA 3102 onwards M4	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M4 ⁷⁾
EOS 7D	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M5 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M5 ⁷⁾	SCA 3102 onwards M5 ⁷⁾	11)	SCA 3102 onwards M5	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3102 onwards M5 ⁷⁾
CONTAX											
MD137/139/MA137/159MM/RTSII/167MT/ RTS III/ST/G1/G2/	standard foot 301 ⁷⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾	11)	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾
Aria/RX/AX/645/N1	standard foot 301 ⁷⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾	11)	SCA 3802 ⁸⁾	SCA 3802 ⁸⁾ + cable SCA 3000 C	SCA 3802 ⁸⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

FUJIFILM

FinePix S1/S2 Pro	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 3402 (M or M2)	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 3402 (M or M2)	SCA 3402 (M or M2)	SCA 343 ⁸⁾ + converter cable SCA 500 C 4)8)	SCA 3402 (M or M2)	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A
FinePix S3 Pro	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 onwards M4 ¹⁰⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M4
FinePix S5 Pro	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 onwards M7 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M7 ⁷⁾

HASSELBLAD

500ELX/503CX/553ELX/205TCC	SCA 390 ²⁾	SCA 390 ²⁾ + cable SCA 300 A	SCA 390 ²⁾ + cable SCA 300 A	SCA 390 ²⁾	SCA 390 ²⁾ + cable SCA 300 A	SCA 390 ²⁾	SCA 390 ²⁾	SCA 390 ²⁾ + converter cable SCA 500 C ³⁾⁸⁾	SCA 390 ²⁾	SCA 390 ²⁾ + cable SCA 300 A	SCA 390 ²⁾
201/203	SCA 390 ²⁾ + bracket 40-36	SCA 390 ²⁾ + cable SCA 300 A + bracket 50-35	SCA 390 ²⁾ + cable SCA 300 A + bracket 50-35	SCA 390 ²⁾ + bracket 40-36	SCA 390 ²⁾ + cable SCA 300 A + bracket 50-35	SCA 390 ²⁾ + bracket 40-36	SCA 390 ²⁾ + bracket 40-36	SCA 390 ²⁾ + converter cable SCA 500 C ³⁾⁸⁾ + bracket 50- 35	SCA 390 ²⁾ + bracket 40-36	SCA 390 ²⁾ + cable SCA 300 A + bracket 50-35	SCA 390 ²⁾ + cable SCA 300 A + bracket 50-35
H1/H2/H3	standard foot 301 ⁷⁾	SCA 3902 ²⁾ + cable SCA 3000 C	SCA 3902 ²⁾ + cable SCA 3000 C	SCA 3902 ²⁾	SCA 3902 ²⁾ + cable SCA 3000 C	SCA 3902 ²⁾⁵⁾	SCA 3902 ²⁾	11)	SCA 3902 ²⁾	SCA 3902 ²⁾ + cable SCA 3000 C	SCA 3902 ²⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

KODAK

DCS-760	standard foot 301 ⁷⁾	SCA 3452 ²⁾⁸⁾ + cable SCA 3000 C	SCA 3452 ²⁾⁸⁾ + cable SCA 3000 C	SCA 3452 ²⁾⁸⁾	SCA 3452 ²⁾⁸⁾ + cable SCA 3000 C	SCA 3452 ²⁾⁸⁾	SCA 3452 ²⁾⁸⁾	11)	SCA 3452 ²⁾⁸⁾	SCA 3452 ²⁾⁸⁾ + cable SCA 3000 C	SCA 3452 ²⁾⁸⁾
DCS-Pro 14n/DCS SLR/N	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 ⁷⁾ (M or M2)	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 ⁷⁾ (M or M2)	SCA 3402 ⁷⁾ (M or M2)	11)	SCA 3402 ⁷⁾ onwards M	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 ⁷⁾ onwards M

LEICA

R4/R4S	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾	SCA 351 ⁸⁾	11)	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾
R5/R-E/R6/R6-2/R7	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + converter cable SCA 500C ⁴⁾⁸⁾	SCA 351 ⁸⁾	SCA 351 ⁸⁾ + cable SCA 300 A	SCA 351 ⁸⁾
R8/R9/M6 TTL/M7	standard foot 301 ⁷⁾	SCA 3502 onwards M + cable SCA 3000 C	SCA 3502 onwards M + cable SCA 3000 C	SCA 3502 onwards M	SCA 3502 onwards M + cable SCA 3000 C	SCA 3502 onwards M	SCA 3502 onwards M	11)	SCA 3502 onwards M	SCA 3502 onwards M + cable SCA 3000 C	SCA 3502 onwards M
M8/M8.2/M9	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	SCA 3502 onwards M4 ⁷⁾	11)	SCA 3502 onwards M4	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4
Digilux 2/CM	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	SCA 3502 onwards M4 ⁷⁾	11)	SCA 3502 onwards M4	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

Digilux 3	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁵⁾⁷⁾	SCA 3202 onwards M5 ⁷⁾	11)	SCA 3202 onwards M5 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁷⁾
V-Lux 1/D-Lux 4	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6 ⁵⁾⁷⁾	SCA 3202 onwards M6 ⁷⁾	11)	SCA 3202 onwards M6 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6 ⁷⁾

MAMIYA

RZ67/RZ67 PRO-II	SCA 395 ²⁾	SCA 395 ²⁾ + cable SCA 300 A	SCA 395 ²⁾ + cable SCA 300 A	SCA 395 ²⁾	SCA 395 ²⁾ + cable SCA 300 A	SCA 395 ²⁾	SCA 395 ²⁾	SCA 395 ²⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 395 ²⁾	SCA 395 ²⁾ + cable SCA 300 A	SCA 395 ²⁾
645 PRO TL	SCA 396 ²⁾ + SCA 300E + bracket 40-36	SCA 396 ²⁾	SCA 396 ²⁾	SCA 396 ²⁾ + SCA 300E + bracket 40-36	SCA 396 ²⁾	SCA 396 ²⁾ + SCA 300E + bracket 40-36	SCA 396 ²⁾ + SCA 300E + bracket 40-36	SCA 396 ²⁾ + SCA 300 E + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 396 ²⁾ + SCA 300E + bracket 40-36	SCA 396 ²⁾	SCA 396 ²⁾ + SCA 300E + bracket 50-35
645AF/645AFD	-	SCA 3952 ²⁾ + cable SCA 3000C	SCA 3952 ²⁾ + cable SCA 3000C	SCA 3952 ²⁾	SCA 3952 ²⁾ + cable SCA 3000C	SCA 3952 ²⁾	SCA 3952 ²⁾	11)	SCA 3952 ²⁾	SCA 3952 ²⁾ + cable SCA 3000C	SCA 3952 ²⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

MINOLTA											
X300/X300S/X370/X370N/XD/XG/CLE/ X500/X570/ X700/5000/7000/9000	SCA 331 ⁸⁾	SCA 331 ⁸⁾ + cable SCA 300 A	SCA 331 ⁸⁾ + cable SCA 300 A	SCA 331 ⁸⁾	SCA 331 ⁸⁾ + cable SCA 300 A	SCA 331 ⁸⁾	SCA 331 ⁸⁾	SCA 331 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 331 ⁸⁾	SCA 331 ⁸⁾ + cable SCA 300 A	SCA 331 ⁸⁾
Dynax/Maxxum/Alpha 3000i/3700i/7000i/7700i/8000i/8700i/ SPxi/2xi/5xi/5/ 300si/404si/450si Date/500si/500si Super/505si/ Vectis S1/800si/9/5000i/ 5700i/3xi/7xi/7/9xi/600si/700si/60	-	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M	SCA 3302 onwards M	-	SCA 3302 onwards M	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M
Dynax 3L/40	-	-	-	-	-	-	-	-	-	-	-
RD 175/RD 3000	-	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M	SCA 3302 onwards M	11)	SCA 3302 onwards M	SCA 3302 onwards M + cable SCA 3000 C	SCA 3302 onwards M
Dimage 5/7/7i/7Hi/A1/A2	-	-	-	SCA 3302 onwards M4	SCA 3302 onwards M4 + cable SCA 3000 C	SCA 3302 onwards M4	SCA 3302 onwards M4	-	SCA 3302 onwards M4	-	SCA 3302 onwards M4
Dimage Z1/Z2/Z3/Z5/Z6/A200	-	-	-	SCA 3302 onwards M5	SCA 3302 onwards M5 + cable SCA 3000 C	SCA 3302 onwards M5	SCA 3302 onwards M5	-	SCA 3302 onwards M5	-	SCA 3302 onwards M5
Dynax 5D/7D	-	-	-	SCA 3302 onwards M5 ⁷⁾	SCA 3302 onwards M5 ⁷⁾ + cable SCA 3000 C	SCA 3302 onwards M5 ⁷⁾	SCA 3302 onwards M5 ⁷⁾	-	SCA 3302 onwards M5	-	SCA 3302 onwards M5 ⁷⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

NIKON											
F3	SCA 344 ⁸⁾ + SCA 300 E	SCA 344 ⁸⁾	SCA 344 ⁸⁾	SCA 344 ⁸⁾ + SCA 300 E	SCA 344 ⁸⁾	SCA 344 ⁸⁾ + SCA 300 E	SCA 344 ⁸⁾ + SCA 300 E	11)	SCA 344 ⁸⁾ + SCA 300 E	SCA 344 ⁸⁾	SCA 344 ⁸⁾ + SCA 300 E
FE/EM/FG-20/FM-2/FE-2/FA/FG/ F301/N2000/F601M/FM-3A	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾
F401/F401s/F501/F50/N50/F60/F65/ N4004/N2020/F80/F801/F801s/N8008/ F401x/F601AF/F90/N90/F70/N70/F75/ F90x/F4/F4s/F5/Pronea 600i/F100	SCA 343 ⁸⁾	SCA 3402 M to M5 + cable SCA 3000 C	SCA 3402 M to M5 + cable SCA 3000 C	SCA 3402 (M or M2)	SCA 3402 M to M5 + cable SCA 3000 C	SCA 3402 (M or M2)	SCA 3402 (M or M2)	SCA 343 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 3402 onwards M	SCA 3402 M to M5 + cable SCA 3000 C	SCA 3402 onwards M
D1/D1X/D1H/D100	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 M2 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 M2 ⁷⁾	SCA 3402 M2 ⁷⁾	11)	SCA 3402 onwards M2 ¹⁰⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M2
D3000/D40/D40x/D50/D60/ D70/D70s/D700/D80/D90 Coolpix 8400/8800/P5000/P5100	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 onwards M8 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M8 ⁷⁾
D5000	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 onwards M9 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M9 ⁷⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

D2X/D2H/ F6/	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 M6 and M7 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 M6 and M7 ⁷⁾
D200/D3/D3x/D300/D300s	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3402 onwards M8 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3402 onwards M8 ⁷⁾
Coolpix 950/990/995/4500 + Nikon SK-E900 oder AS-E900	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 3402 onwards M	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 3402 onwards M
Coolpix 5000/5400	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾	SCA 343 ⁸⁾	SCA 343 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 3402 onwards M	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 3402 onwards M
Coolpix 5700/8700	SCA 343 ⁸⁾ + SCA 300 D	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + SCA 300 D	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + SCA 300 D	SCA 343 ⁸⁾ + SCA 300 D	SCA 343 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 343 ⁸⁾ + SCA 300 D	SCA 343 ⁸⁾ + cable SCA 300 A	SCA 343 ⁸⁾ + SCA 300 D

OLYMPUS											
E-10/E-20P/C-2500L/C-750/C-770/ C-5050/C-5060/C-8080/SP-350	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M	SCA 3202 onwards M + cable SCA 3000 C	SCA 3202 onwards M ⁵⁾	SCA 3202 onwards M	11)	SCA 3202 onwards M	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M

Meanings of exponents see last page!

Subject to changes! Metz-Werke, Technical Support

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

E-1/C-7070	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M3 ⁷⁾	SCA 3202 onwards M3 ⁷⁾ + cable SCA 3000 C	SCA 3202 onwards M3 ⁵⁾⁷⁾	SCA 3202 onwards M3 ⁷⁾	11)	SCA 3202 onwards M3	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M3
E-30/E-300/E-330/E-400/E-410/E-420/ E-450/E-500/E-510/E-520/E-620/ E-3/SP-570/PEN E-P1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁷⁾	SCA 3202 onwards M5 ⁷⁾ + cable SCA 3000 C	SCA 3202 onwards M5 ⁵⁾⁷⁾	SCA 3202 onwards M5 ⁷⁾	11)	SCA 3202 onwards M5 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁷⁾
E-100RS/C-2100UZ/C-2040Z/C-3000Z/ C-3030Z/C-3040Z/C-4000Z/C-4040Z/ C-700UZ + Olympus FL-BK01/FL-CB01	standard foot 301 ⁷⁾	-	-	SCA 3202 onwards M2	SCA 3202 onwards M2 + cable SCA 3000 C	SCA 3202 onwards M2 ⁵⁾	SCA 3202 onwards M2	11)	SCA 3202 onwards M2	-	SCA 3202 onwards M2

PANASONIC											
DMC-LC1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4 ⁷⁾	SCA 3502 onwards M4 ⁷⁾	11)	SCA 3502 onwards M4	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3502 onwards M4
DMC-L1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5 ⁵⁾⁷⁾	SCA 3202 onwards M5 ⁷⁾	11)	SCA 3202 onwards M5	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M5
DMC-FZ50/LX-3	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6 ⁵⁾⁷⁾	SCA 3202 onwards M6 ⁷⁾	11)	SCA 3202 onwards M6	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M6
DMC-L10/G1/GH1/GF1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M7 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M7 ⁵⁾⁷⁾	SCA 3202 onwards M7 ⁷⁾	11)	SCA 3202 onwards M7 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3202 onwards M7 ⁷⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

PENTAX											
ME-Super/ME-F/MG/MV/MV-1/Progr. A/ P-30/P-30N/P-30T/P-3N/P-50/A3/A3000/ MZ-M	SCA 372 ⁷⁾⁸⁾	SCA 372 ⁷⁾⁸⁾ + cable SCA 300 A	SCA 372 ⁷⁾⁸⁾ + cable SCA 300 A	SCA 372 ⁷⁾⁸⁾	SCA 372 ⁷⁾⁸⁾ + cable SCA 300 A	SCA 372 ⁷⁾⁸⁾	SCA 372 ⁷⁾⁸⁾	SCA 372 ⁷⁾⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 372 ⁷⁾⁸⁾	SCA 372 ⁷⁾⁸⁾ + cable SCA 300 A	SCA 372 ⁷⁾⁸⁾
LX (mit Sucherschuh)/Super A/645	SCA 372 ⁸⁾	SCA 372 ⁸⁾ + cable SCA 300 A	SCA 372 ⁸⁾ + cable SCA 300 A	SCA 372 ⁸⁾	SCA 372 ⁸⁾ + cable SCA 300 A	SCA 372 ⁸⁾	SCA 372 ⁸⁾	SCA 372 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 372 ⁸⁾	SCA 372 ⁸⁾ + cable SCA 300 A	SCA 372 ⁸⁾
SFX/SF-1/SFXN/SF1N/SF7/SF10	SCA 372 ⁸⁾	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M	SCA 3702 onwards M	SCA 372 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 3702 onwards M	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M
Z-1/Z-1P/Z-10/Z-20/Z-50P/PZ-1/PZ-10/ PZ-20/645N/MZ-3/MZ-5/MZ-5N/MZ-10/ MZ-50/MZ-6/Z-70/MZ-7	standard foot 301 ⁷⁾	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M	SCA 3702 onwards M	11)	SCA 3702 onwards M	SCA 3702 onwards M + cable SCA 3000 C	SCA 3702 onwards M
*ist/*istDL/K100D/K100D Super/ K110D/K10D/K200D/K20D/K-m	standard foot 301 ⁷⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾	SCA 3702 onwards M ⁷⁾	11)	SCA 3702 M2 ¹⁰⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾
K-7, K-x	standard foot 301 ⁷⁾	SCA 3702 onwards M3 ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M3 ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M3 ⁷⁾	SCA 3702 onwards M3 ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M3 ⁷⁾	SCA 3702 onwards M3 ⁷⁾	11)	SCA 3702 onwards M3 ¹⁰⁾	SCA 3702 onwards M3 ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M3 ⁷⁾

Previous flash units with SCA system in combination with current adapters:											
Analog & digital cameras in alphabetical line of camera manufacturers:	28 CT-5	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	32 CT-4	32 Z-2	45 CT-3	40 MZ-1	40 MZ-1i	45 CT-5	54 MZ-3	60 CT-4	70 MZ-4
	30 TTL-1(i)		32 CT-8	32 MZ-3	45 CL-3	40 MZ-2	40 MZ-3i	60 CT-2	54 MZ-4	70 MZ-5	
	32 CT-2				45 CT-4 ⁶⁾	40 MZ-3					
	32 CT-3(i)				45 CL-4	50 MZ-5					
	36 CT-2										
	36 CT-3										
*istD/*istDS	standard foot 301 ⁷⁾	SCA 3702 onwards M ⁹⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁹⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁹⁾	SCA 3702 M ⁹⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁹⁾	SCA 3702 onwards M ⁹⁾	11)	SCA 3702 M2 ⁹⁾	SCA 3702 onwards M ⁹⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁹⁾
RICOH											
XR-1S/KR-5S/XR-2S/XR-S/XR-F/XR-7/ XR-6/XR-20SP/KR-10/KR-10S/KR-30SP/ KR-10M/XR-P/XR-X/XR-M	SCA 364 ⁸⁾	SCA 364 ⁸⁾ + cable SCA 300 A	SCA 364 ⁸⁾ + cable SCA 300 A	SCA 364 ⁸⁾	SCA 364 ⁸⁾ + cable SCA 300 A	SCA 364 ⁸⁾	SCA 364 ⁸⁾	SCA 364 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 364 ⁸⁾	SCA 364 ⁸⁾ + cable SCA 300 A	SCA 364 ⁸⁾
XR-X 3 PF	SCA 364 M1 ⁸⁾	SCA 364 M1 ⁸⁾ + cable SCA 300 A	SCA 364 M1 ⁸⁾ + cable SCA 300 A	SCA 364 M1 ⁸⁾	SCA 364 M1 ⁸⁾ + cable SCA 300 A	SCA 364 M1 ⁸⁾	SCA 364 M1 ⁸⁾	SCA 364 M1 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 364 M1 ⁸⁾	SCA 364 M1 ⁸⁾ + cable SCA 300 A	SCA 364 M1 ⁸⁾
ROLLEI											
SL2000F/3001/3003/SL66E/SL66X/SL66SE/ 2,8GX/SL6001/SL6002/SL6006/SL6008	SCA 356 ²⁾³⁾	SCA 356 ²⁾ + cable SCA 300 A	SCA 356 ²⁾ + cable SCA 300 A	SCA 356 ²⁾³⁾	SCA 356 ²⁾ + cable SCA 300 A	SCA 356 ²⁾³⁾	SCA 356 ²⁾³⁾	SCA 356 ²⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 356 ²⁾³⁾ + SCA 300 D	SCA 356 ²⁾ + cable SCA 300 A	SCA 356 ²⁾³⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

SL6008AF	SCA 356 ²⁾³⁾	SCA 356 ²⁾ + cable SCA 300 A	SCA 356 ²⁾ + cable SCA 300 A	SCA 3562 ²⁾	SCA 356 ²⁾ + cable SCA 300 A	SCA 3562 ²⁾⁵⁾	SCA 3562 ²⁾	SCA 356 ²⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 3562 ²⁾	SCA 356 ²⁾ + cable SCA 300 A	SCA 3562 ²⁾
----------	-------------------------	---	---	------------------------	---	--------------------------	------------------------	--	------------------------	---	------------------------

SAMSUNG

Digimax Pro 815	-	-	-	-	-	-	-	-	-	-	-
GX-1L/GX-1S/GX-10/GX-20	standard foot 301 ⁷⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾	SCA 3702 onwards M ⁷⁾	11)	SCA 3702 M2 ¹⁰⁾	SCA 3702 onwards M ⁷⁾ + cable SCA 3000 C	SCA 3702 onwards M ⁷⁾

SIGMA

SA 300/SA 300 N/SA-5	-	SCA 3601 8) + cable SCA 3000 C	SCA 3601 8) + cable SCA 3000 C	SCA 3601 ⁸⁾	SCA 3601 8) + cable SCA 3000 C	SCA 3601 ⁸⁾	SCA 3601 ⁸⁾	11)	standard foot 301 ⁷⁾	SCA 3601 8) + cable SCA 3000 C	standard foot 301 ⁷⁾
SD-9/SD-10/SD-14	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾

SONY

DSC-F505/DSC-F707/DSC-S75/DSC-S85/MVC-CD200	-	-	-	SCA 3602 M4 ⁸⁾	-	SCA 3602 M4 ⁵⁾⁸⁾	SCA 3602 M4 ⁸⁾	-	SCA 3602 M4 ⁸⁾	-	SCA 3602 M4 ⁸⁾
DSC-F717/DSC-V1/DSC-V3	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3602 M4 ⁸⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

DSC-F828/DSC-R1	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3602 M4 ⁸⁾	SCA 3602 M4 ⁸⁾ + cable SCA 3000 C	standard foot 301 ⁷⁾	standard foot 301 ⁷⁾	11)	SCA 3602 M4 ⁸⁾	standard foot 301 ⁷⁾ + cable SCA 300 A	SCA 3602 M4 ⁸⁾
A100/A200/A700/	-	-	-	SCA 3302 onwards M7 ⁷⁾	SCA 3302 onwards M7 ⁷⁾ + cable SCA 3000 C	SCA 3302 onwards M7 ⁷⁾	SCA 3302 onwards M7 ⁷⁾	-	SCA 3302 onwards M7	-	SCA 3302 onwards M7 ⁷⁾
A230/A300/A330/A350/A380/ A550/A850/A900	-	-	-	SCA 3302 M8 ⁷⁾	SCA 3302 M8 ⁷⁾ + cable SCA 3000 C	SCA 3302 M8 ⁷⁾	SCA 3302 M8 ⁷⁾	-	SCA 3302 M8	-	SCA 3302 M8 ⁷⁾

YASHICA											
FX-D Quartz/107MP/108MP/109MP/ FX-3 Super/FX-7 Super/FX103/ 200AF/230AF/270AF/300AF	SCA 382 ⁸⁾	SCA 382 ⁸⁾ + cable SCA 300 A	SCA 382 ⁸⁾ + cable SCA 300 A	SCA 382 ⁸⁾	SCA 382 ⁸⁾ + cable SCA 300 A	SCA 382 ⁸⁾	SCA 382 ⁸⁾	SCA 382 ⁸⁾ + converter cable SCA 500 C ⁴⁾⁸⁾	SCA 382 ⁸⁾	SCA 382 ⁸⁾ + cable SCA 300 A	SCA 382 ⁸⁾

Analog & digital cameras in alphabetical line of camera manufacturers:	Previous flash units with SCA system in combination with current adapters:										
	28 CT-5 30 TTL-1(i) 32 CT-2 32 CT-3(i) 32 CT-7 36 CT-2 36 CT-3	Power Griff G15 1) with: 28 CT-5 30 TTL-1(i) 32 CT-3(i) 32 CT-7 36 CT-3	32 CT-4 32 CT-8	32 Z-2 32 MZ-3	45 CT-3 45 CL-3 45 CT-4 ⁶⁾ 45 CL-4	40 MZ-1 40 MZ-2 40 MZ-3 50 MZ-5	40 MZ-1i 40 MZ-3i	45 CT-5 60 CT-2	54 MZ-3 54 MZ-4	60 CT-4	70 MZ-4 70 MZ-5

Meanings:	
1)	The mentioned above flash units can be turned to a hand held flash unit by a power grip G15 requiring other adapters.
2)	SCA adapter sold by the camera manufacturer.
3)	For using a mecablitz 32CT-7 or 40MZ... the spacer SCA 300 D is required!
4)	A mecablitz 45CT-5 below serial number 106001 or 60CT2 below serial number 46830 must be up-grade! SCA 500 C discontinued!
5)	mecablitz 40 MZ-2 only onwards serial number 155201!
6)	45 CT-4: with SCA 3000 C M1 only onwards serial number 205180 of flash unit usable!
7)	Only automatic-flash-mode or manual-flash-mode are possible!
8)	No longer available!
9)	Only standard TTL mode are possible!
10)	MB 54 MZ-3: only auto flash mode or manual mode are possible!
11)	Connection by standard sync cable and if necessary additional by sync adapter from the accessory trade. Only automatic-flash-mode or manual-flash-mode are possible.
M..	Described the needed version of particular adapter!